Technaxx®

LED Power Bank TX–15

User Manual

The Declaration of Conformity for this device is under: www.technaxx.de/ (in bottom bar “Konformitätserkärung”)

Features

- Suitable for nearly all kinds of mobile phones and digital products with an USB port (e.g. iPhone, iPad, iPod, MP3/MP4, GPS, Bluetooth device, Tablet PC)
- Precise IC protector which avoid over-charging/discharging and short circuit
- Can be used as torch light with 4 bright LEDs on the side
- Intelligent single-chip controls charging cycle
- Steady and high efficiency and long using time
- Load capacity of 4400mAh
- Input / Output: DC 5V ~ 1000mA
- Small and handy, ideal for traveling



Part overview

Switch Button (for Power + Torch function)
Input port
USB output port
4 LEDs (indicating the loading status or their function is the torch light)

[Please charge the Power Bank once every 3 months if not be used.]

Charging (~6 hours) of the device itself

❶ Put the switch of the Power Bank to the position OFF.
❷ Connect the included USB cable to an USB port of your computer. Connect the other end of the cable to the Power Bank’s input port.
❸ The white LEDs at the side of the device are shining (depends on the charging status). In case the battery is fully charged, all four LEDs are shining. Charging time is ~6 hours.

Charging of your mobile phone or another device

❶ Connect the mobile phone or other device with the USB port (output port) of Power Bank.
❷ Put the switch of the Power Bank to the position of the “Battery symbol”.
❸ Then the charging of your mobile phone or other device starts at once.
[Power Bank can charge your iPhone ~1 ½ times] There might be different charging circuits in different kinds of mobile phones. Use the enclosed cable instead of other cables or adapters.

Torch function of the Power Bank

❶ Put the switch of the Power Bank to the position of the “Bulb symbol”.
❷ Then all four LEDs of the Power Bank are shining white constantly and it can be useed as very bright torch.
❸ For turning off the torch function put the switch to the position “OFF”.

Package Contents: LED Power Bank TX–15, DC3.5 USB cable, User Manual

Dimensions / Weight device: 88.5 x 51 x 28mm / 115g

Security and Disposal Hints for Batteries: Hold children off batteries. When a child swallowed a battery go to a doctors place or bring the child into a hospital promptly! Look for the right polarity (**+**) and (**--**) of batteries! Always change all batteries, never use old and new batteries or batteries of different types together. Never short batteries. Do NOT open, deform or load up batteries! There is a **risk of injury** by battery leakage fluid! NEVER throw batteries into fire! There is a **risk of explosion**!

Hints for Environment Protection: Packages materials are raw materials and can be recycled. Do not disposal old devices or batteries into the domestic waste. **Cleaning:** Protect the device from contamination and pollution. Only clean the device with soft cloth/drapery, avoid using rough or coarse-grained materials. Do NOT use solvents or other aggressive cleaner. Wipe the device after cleaning accurately. **Important Notice:** Should battery fluid leak from a battery, wipe the battery-case with a soft cloth dry.

Distributor (Inverkehrbringer):
Technaxx Deutschland GmbH & Co.KG, Kruppstr. 105, 60388 Frankfurt a.M., Germany